Miltech Simulations MV-22B Tiltrotor

Center Console



Figure: Center Console

1. **Landing Gear Indicator**: Indicates status of the nose, left and right gears
2. **Landing Gear Lever**
3. **Emergency Gear Release:** INOP
4. **Forward Camera Control:** INOP
5. **Flaps:**
6. In CONV/VTOL Config, the Flaps are always in Auto-mode (position A), meaning that the flaps are autocommanded depending on nacelles position and airspeed.
7. In APLN config, the flaps can be manually controlled, via this lever or the standard flaps controllers.

1. Airspeed > 220 knots, Flaps 0
2. Airspeed 180 - 220 knots, Flaps >10
3. Airspeed < 180 knots, all flaps positions are allowed.

8. **↔ Nacelle Control Disable Switches:** INOP

9. **Parking Brake**