
Miltech Simulations CH47D

Overview - Exterior



External Overview

1. **Aircraft Fuselage**
2. **Front Side Door:** Consists of two parts - a sliding top half, and a bottom half with stairs. More information on how to operate the doors, read Electronic Flight Bag (EFB)
3. **Front Landing Gear:** Non-retractable, fixed
4. **Rear Landing Gear:** Non-retractable, can swivel
5. **Main Ramp:** Consists of two parts - a sliding top half, and a bottom half. More information on how to operate the doors, read Electronic Flight Bag (EFB)
6. **Ramp Slide:** More information on how to operate the doors, read Electronic Flight Bag (EFB)
7. **T55 Engine**
8. **Front Rotor:** Counterclockwise Rotation
9. **Back Rotor:** Clockwise Rotation
10. **Pilot Side Emergency Cockpit Door:** These doors are emergency use only, and therefore once jettisoned they cannot be closed unless you restart the flight.